

# *ComforTable*

*-by Breis*

## **PACS Workstation Tables**



**Well being and Flexibility for the Radiologist  
Quality and Efficiency for the Service**

# Standard Features

**Motorized height adjustment from 700 to 1200 mm**

**Power and network inlets at floor level eliminates dangerous and inconvenient cables**

**2 power inlets (1 for UPS)**

**10 power outlets - for PC, monitors, other accessories etc, incl 2 UPS outputs**

**Separate fixed-level monitor shelf**

**Integrated cable basket for tidy cabling**

**Padded arm rest**

**Integrated keypad**

**Choice of desktop width - 1420 / 1660 / 1960 mm**

**Other sizes available on request.**

**Breis & Co design and build ergonomic PACS workstations for diagnostic softcopy reading. The fully adjustable *ComforTable* enables radiologists to work in conditions of enhanced utility and comfort. Automatic control of ambient and background illumination ensures constant conditions as stipulated by DICOM Part 14.**



*Low level*



*Raised level*

***ComforTable* is designed and built to Swedish standards of ergonomics and craftsmanship**

# Options



**Sound absorbing background screen covered in microfibre for privacy. Lower screen/modesty screen also available.**

**Upward and downward lighting with dimmer.**



**Background screen and illumination. Also includes automatic control of the background and ambient light levels for a constant working environment.**



**Motorized table tilt (0-10 degrees). When ordering table tilt, a monitor stand should also be ordered.**



**Monitor stand for 3, 4 or 5 monitors, with electrical up/down adjustment. Manual height adjustment also available.**



**Adjustable keyboard tray.**

**Also shown: Padded armrest. (Standard feature)**



**PC Holder with sound absorbing and theft protected cabinet. (Mounted on left and/or right side)**



**Wider table for up to 5 monitors.**



**Foot-rest with two positions. Can be used both in seated and standing position.**



**Additional shelves, raised or level with the main desk. (Left or right)**



**Light box mounted on left or right side. Can be adjusted in height, rotated and turned in/out.**



**USB hub for easy connection of accessories like speech mike and bar code readers.**



**Built-in UPS unit. Intended only for safe shut down of the PC.**



**10 power outlets for monitors, PC and other accessories. (Standard feature)**



Built-in control panel

## Specifications

- **Maximum power consumption** 200 W
- **Mains** 230/117VAC, 50/60Hz
- **Maximum total load** 180 kg
- **Table surface height** 700 - 1200 mm
- **Total height (inc. lighting)** 1500 - 2000 mm
- **Weight (without PC/monitors)** 140 kg
- **Maximum tilt** 10°
- **Maximum total monitor weight with electrical lift** 45 kg
- **Maximum total monitor weight with no stand or manual monitor stand** 60 kg
- **Table depth (minimum door opening)**
  - Assembled** 880 mm
  - Partly dis-assembled** 750 mm

